

# PROGRAM YOUR KEYBOX

## Turn on keybox:

- ◆ For Bluetooth keyboxes, press up and then release the bottom of the keybox (a light located in the front window of the keybox will continue to flash while the Bluetooth is on).
- ◆ For infrared keyboxes, press the Supra eKEY fob button and point the front of the fob toward the front window of the keybox (a light located on the top of the fob will continue to flash while the fob is actively sending commands to the keybox).

## Change Shackle Code:

1. Turn on the keybox.
2. Open the Supra eKEY app and select **My Keyboxes**.
3. Select a keybox.
4. Select **Program Keybox**.
5. Select **Shackle Code**.
6. Enter and verify new shackle code.
7. Select **Save**.
8. Select **Program**.
9. Enter old shackle code.

## Enable or Disable Require CBS Code:

1. Turn on the keybox.
2. Open the Supra eKEY app and select **My Keyboxes**.
3. Select a keybox.
4. Select **Program Keybox**.
5. Select **Require CBS** to enable or disable.
6. Select **Program**.
7. Enter shackle code.

## Enable or Disable Require Feedback:

1. Turn on the keybox.
2. Open the Supra eKEY app and select **My Keyboxes**.
3. Select a keybox.
4. Select **Program Keybox**.
5. Select **Require Feedback** to enable or disable.
6. Select **Program**.
7. Enter shackle code.

## Enable or Disable Timed Access:

1. Turn on the keybox.
2. Open the Supra eKEY app and select **My Keyboxes**.
3. Select a keybox. **Program a Keybox**
4. Select **Program Keybox**.
5. Select **Timed Access** to enable or disable.
6. Select desired access hours.
7. Select **Program**.
8. Enter shackle code.

## View Last Keybox Read:

1. Open the Supra eKEY app and select **My Keyboxes**.
2. Select a keybox.
3. Select **Program Keybox**.
4. Select **Read**.
5. Select an activity to view details or select **Delete All** to delete all activities.

## Delete a Keybox:

1. Open the Supra eKEY app and select **My Keyboxes**.
2. Select a keybox.
3. Select **Program Keybox**.
4. Select **Delete** then **Yes** to confirm.

## Change Your PIN:

1. Open the Supra eKEY app and select **MORE**
2. Select **About e-key App**
3. Select **Change Pin**

